

ATTENTION: All Total Door Distributors/Sales Reps

DATE: August 22, 2016

REGARDING: Installation Screws X65

Total Door Systems has recently changed the X65 installation screws to a TEK 3 pancake head, #12-14x1". A **#2 Phillips square drive** bit or **#2 square** bit will be required, #2 Phillips cannot be used. There is a label on the box and bag of installation screws that are supplied with every door and parts order stating the correct bit to be used.

The reason for the change, is the larger profile of the head on the previous screw was causing installation of the door into the hinge housing to be difficult at times. Also, the length has been increased to allow for ample threads to grab the frame when shims are used.

If you have any questions, please contact the factory.