

Q289 Threaded




Q34  
Hub Stop



## Required Parts

- 1 - Q289 Threaded
- 1 - Q34 Hub Stop
- 1 - Q13 Hub
- 1 - X24 Set Screw
- 1 - Q18 Spring Lever
- 1 - Y42 Spring


Q13 Hub



X24 Set  
Screw

Q18 Spring  
Lever

Y42 Spring



**Presetup  
LR Function**